

AEROBLADE/WINGBAR/EVO SQUARE BAR FOOT SPACING

FOOT	43 (108cm)		47 (118cm)		50 (127cm)		53 (135cm)		60 (150cm)	
	MIN"	MAX"	MIN"	MAX"	MIN"	MAX"	MIN"	MAX"	MIN"	MAX"
400XTR	22	37 1/4	26	41 1/4	29 3/4	45	32 3/4	48	38 1/2	54
430R	26 1/2	42	30 1/2	46	33 3/4	49	36 3/4	52	42 3/4	59
450R	25 3/4	36 1/2	29 3/4	40 1/2	32 3/4	43 1/2	35 3/4	46 1/2	42 3/4	53 1/2
460R	29 1/2	42 3/4	33 1/2	46 3/4	36 1/2	49 3/4	39 1/2	52 3/4	46 1/2	59 3/4
480R	23 1/4	35 1/8	27 1/4	39 1/8	30 1/4	42 1/8	33 1/4	45 1/8	40 1/4	52 1/8
7104	28 1/2	37.5	33 1/2	42 1/2	37	46	40 1/2	49 1/2	46 1/2	55 1/2
7105	23 1/4	35 1/8	27 1/4	39 1/8	30 1/4	42 1/8	33 1/4	45 1/8	40 1/4	52 1/8
7106	29 1/2	42 3/4	33 1/2	46 3/4	36 1/2	49 3/4	39 1/2	52 3/4	46 1/2	59 3/4
7107	27 1/2	38 1/2	31 1/4	42 1/4	35	46	38 1/4	49 1/4	43 3/4	55

RAPID BAR (RB) FOOT SPACING

FOOT	RB43		RB47		RB53		RB60	
	MIN"	MAX"	MIN"	MAX"	MIN"	MAX"	MIN"	MAX"
400XTR	26	36 1/4	30	40 1/4	36 3/4	47	42 1/2	53
430R	30 1/2	40 3/4	34 1/2	47	40 3/4	51	46 3/4	58
450R	26 3/4	35 1/2	33 3/4	39 1/2	39 3/4	45 1/2	46 3/4	52 1/2
460R	33 1/2	41 3/4	37 1/2	39 1/2	43 1/2	51 3/4	50 1/2	58 3/4
480R	27 1/4	34 1/8	31 1/4	38 1/8	37 1/4	44 1/8	44 1/4	51 1/8

NOTE:

400 Aero & 480 Traverse Feet:

1. Look up foot placement measurements found in the vehicle fit kit instructions (these can be found @ www.thule.com)
2. Refer to chart to see what bars are compatible with your measurements.
3. Using a tape measure, install rack on vehicle as you normally would (Note: Upgrading your bar length renders the SmartSlides obsolete).

430 Tracker II, 450 Crossroads & 460 Podium Feet:

1. Measure from the center of the rail, or fixed point to get proper footplacement measurement.
2. Refer to chart to see what bars are compatible with your measurements